


Airgun, GNB, MS, CO2, 4.5mm, BERSA BP9CC - 17300

BP9CC 4.5mm NON-BLOW BACK



1-01	Frame	1
1-02	Body Seat	1
1-03	Body Cover	1
1-04	Back Cover	1
1-05	Back Cover Catch	1
1-06	Heavy Weight	1
1-07	Trigger	1
1-08	Mag. Catch	1
1-09	Slide Stop	1
1-10	Hammer Stopper	1
1-19	Trigger Connector	1
1-23	Trigger Spring	1
1-24	Slide Stop Spring	1

1-25	Hammer Spring	1
1-26	Mag. Catch Spring	1
1-27	Back Cover Catch Spring	1
1-28	Trigger Connector Spring	1
1-29	Axis	1
1-30	Axis	3
1-31	Axis	1
1-32	Axis	1
1-33	Axis	1
1-36	Screw	1
1-37	Screw	2
1-42	Fixing Axis Spring	1
1-44	Hammer Axis	1
2-01	Slide	1
2-02	Slide Back Cover	1
2-05	Washer	1
2-06	Fixing Axis	1
2-07	Safety	1
2-08	Safety Catch	1
2-09	Screw	1
2-10	Safety Catch Spring	1
2-11	Steel Ball	1
3-01	BB Carry Parts	1
3-04	Outer Barrel	1
3-05	BB Holder	1
3-06	Internal Barrel	1
3-07	BB Pusher	1
3-09	Barrel Tip	1
4-01	Hammer	1
4-03	Axis	1
4-04	Hammer Wheel	1
5-01	Mag. Body	1
5-02	Mag. Cover	1
5-03	BB Follower	1
5-04	Mag. Base	1
5-05	Mag. Inner Pad	1
5-06	Mag. Spring	1
7-01	Valve Chamber	1
7-02	Valve Cover	1
7-03	Valve Ring	1
7-04	Piercer Seal	1
7-05	Fixing Ring	1
7-06	Valve Seal	1
7-07	O-ring	1
7-08	O-ring	1
7-09	Washer	1
7-10	Filter	1
7-11	Piercer	1
7-12	Valve	1
7-13	Valve Spring	1
8-01	Knob Seat	1
8-02	Knob Cover	1
8-04	Piercing Level Screw	1
8-05	Axis	1
8-06	Screw	2

3-09	Barrel Tip	1
4-01	Hammer	1
4-03	Axis	1
4-04	Hammer Wheel	1
5-01	Mag. Body	1
5-02	Mag. Cover	1
5-03	BB Follower	1
5-04	Mag. Base	1
5-05	Mag. Inner Pad	1
5-06	Mag. Spring	1
7-01	Valve Chamber	1
7-02	Valve Cover	1
7-03	Valve Ring	1
7-04	Piercer Seal	1
7-05	Fixing Ring	1
7-06	Valve Seal	1
7-07	O-ring	1
7-08	O-ring	1
7-09	Washer	1
7-10	Filter	1
7-11	Piercer	1
7-12	Valve	1
7-13	Valve Spring	1
8-01	Knob Seat	1
8-02	Knob Cover	1
8-04	Piercing Level Screw	1
8-05	Axis	1
8-06	Screw	2